ROMO HOSES LAND ROVER

ef	Application	Years	Hose	Orig Ref No.
255	Series I Petrol	1948/57	Тор	217273
230	Series I Petrol	1948/57	Bottom	217274
410	Series Petrol	1948/53	By-pass	274874 579792
315				242050
	Series I Petrol	1954/57	By-pass	242056
559	Series I Diesel	1957/58	Тор	508060
493	Series I Diesel	1957/58	Bottom	271117
255	Series II 2 litre Petrol	1958	Тор	268037
230	Series II 2 litre Petrol	1958	Bottom	268038, GRH368
315	Series II 2 litre Petrol	1958	By-pass	242056
559	Series II 2 1/4 litre Petrol & Diesel	1958/60	Тор	247872
836	Series II 2 1/4 litre Petrol & Diesel	1961	Тор	517613, GRH439, 569955
493	Series II 2 1/4 litre Petrol & Diesel	1958/61	Bottom	278539, GRH418
850	Series II 2 1/4 litre Petrol with IIAC Alternator		Bottom	
				543629
623	Series II 2 1/4 litre Petrol with 2AC Alternator		Bottom	530585
441	Series II 2 1/4 litre Petrol & Diesel	1958/61	By-pass	273789, 574871
308	Series II 2 1/4 litre Petrol & Diesel	1958/61	Heater	234063
307	Series II 2 1/4 litre Petrol & Diesel	1958/61	Heater	269567
210	Series II 2 1/4 litre Petrol & Diesel	1958/61	Heater	509754
300N	Series II 2 1/4 litre Petrol & Diesel	1958/61	Front fuel filler	543764
836	Series IIA 2 1/4 litre Petrol & Diesel	1961/67	Ton	517612 CDU420 560055
			Тор	517613, GRH439, 569955
530	Series IIA 2 1/4 litre Petrol & Diesel	1967/71	Тор	577346, GRH585
875	Series IIA 2 1/4 litre Petrol & Diesel	1961/67	Bottom	530556, GRH369, 534130
650	Series IIA 2 1/4 litre Petrol & Diesel	1967/71	Bottom	577344, GRH586, GRH609
				NRC3115
850	Series IIA 2 1/4 litre Petrol with IIAC Alternato	r 1961/67	Bottom	543629
623	Series IIA 2 1/4 litre Petrol with 2AC Alternato	r1961/67	Bottom	530585
441	Series IIA 2 1/4 litre Petrol & Diesel	1961/71	By-pass	273789, 574871
210	Series IIA 2 1/4 litre Petrol & Diesel	1961/67	Round heater	509754
307	Series IIA 2 1/4 litre Petrol & Diesel	1961/67	Round heater	269567
308	Series IIA 2 1/4 litre Petrol & Diesel	1961/67	Round heater	234063
309	Series IIA 2 1/4 litre Petro; & Diesel	1967/71	Flat heater	569154
310	Series IIA 2 1/4 litre Petrol & Diesel	1967/71	Flat heater	569155
311	Series IIA 2 1/4 litre Petrol & Diesel	1967/71	Flat heater	90/569156
300N	Series IIA 2 1/4 litre Petrol & Diesel	1961/71	Front fuel filler	543764
638	Series IIA 2.6 litre Petrol	1967/71	Тор	559876, GRH366
639	Series IIA 2.6 litre Petrol	1967/71	Bottom	552516, GRH371
139	Series IIA 2.6 Petrol	1967/71	Inlet to pump	562915
313				
	Series IIA 2.6 litre Petrol	1967/71	Heater	231895
312	Series IIA 2.6 litre Petrol	1967/71	Square heater	568891
300N	Series IIA 2.6 litre Petrol	1967/71	Front fuel filler	543764
739	Series IIA & IIB 21/4 litre Petrol & Diesel			
	forward control	1966/68	Тор	526891, GRH365
740		1966/68	Bottom	538238, GRH370
441		1966/68	By-pass	273789, 574871
741	Series IIB 2.6 litre Petrol forward control	1966/67	Top	551745
742	Series IIB 2.6 litre Petrol forward control	1966/67	Bottom	
				543605
431	Series IIB 2.6 litre Petrol forward control	1966/67	By-pass	500697
530	Series III 2 1/4 litre Petrol & Diesel	1971/84	Тор	577346, GRH585
650	Series III 2 1/4 litre Petrol & Diesel	1971.84	Bottom	577344, GRH586, GRH609
441	Series III 2 1/4 litre Petrol & Diesel	1971/84	By-pass	574871, 273789
304	Series III 2 1/4 litre Petrol & Diesel	1971/84	Heater	594629
305	Series III 2 1/4 litre Petrol & Diesel	1971.84	Heater	594632
306	Series III 2 1/4 litre Petrol & Diesel	1971/84	Heater	577292
300N	Series III 2 1/4 litre Petrol & Diesel	1971/84	Front fuel filler	543764
0.45		1071/04	Ton	624363, GRH530
245	Series III 2.6 litre Petrol	1971/84	Top	
246	Series III 2.6 litre Petrol	1971/84	Bottom	624364, GRH531
304	Series III 2.6 litre Petrol	1971/84	Heater	594629
305	Series III 2.6 litre Petrol	1971/84	Heater	594632
306	Series III 2.6 litre Petrol	1971/84	Heater	577292
300N	Series III 2.6 litre Petrol	1971/84	Front fuel filler	543764
00014			Zianis trais	OPLISEA
	Stage I V/8	1980/83	Ton	GRHSST
521	Stage I V8	1980/83	Top	GRH551 GRH636 NRC3206
	Stage I V8 Stage I V8 Stage I V8	1980/83 1980/83 1980/83	Top Bottom Front Fuel filler	GRH551 GRH636, NRC3206 543764

1452 90 1453 110 1454 111 1455 111 1456 111 1457 110 1598 90 1599 90 1600 90 441 90 1661 111 1676 110 1673 110 1838 110 1836 90 1837 90 1899N 1910N 1936 111 1852 1853 1561 1960	& 110, V8 & 110, V8 0 4 cylinder Petrol 0 4 cylinder Petrol 0 2 ¼ Diesel & 2 ½ Diesel 0 2 ¼ Diesel & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel 8 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on 8 110 8 110	1983/ 1983/ 1983/ 1983/ 1983/ 1983/ 1984/ 1984/ 1986/ 1986/ 1992/ 1992/	Top Bottom Top Bottom Top Bottom Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater Top	NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308
1452 90 1453 110 1454 111 1455 110 1456 110 1457 110 1598 90 1599 90 1600 90 441 90 1661 110 1676 110 1673 110 1838 110 1836 90 1899N 1910N 1936 110 1852 1853 1561 1960 2024 De	& 110, V8 0 4 cylinder Petrol 0 4 cylinder Petrol 0 2 ½ Diesel & 2 ½ Diesel 0 2 ½ Diesel & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel 8 110 0 2 ½ Petrol 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Alion 0 2 ½ Petrol & Diesel VIN-FA389799 on 8 110 8 110	1983/ 1983/ 1983/ 1983/ 1983/ 1984/ 1984/ 1984/ 1986/ 1986/ 1992/	Top Bottom Top Bottom Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC6403 NRC3664 NRC3664 NRC6404 NRC3976 NRC4850 NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1453 110 1454 110 1455 110 1456 110 1457 110 1598 90 1599 90 1600 90 441 90 1661 110 1673 110 1838 110 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960 2024 De	0 4 cylinder Petrol 0 4 cylinder Petrol 0 2 ½ Diesel & 2 ½ Diesel 0 2 ½ Diesel & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel 8 110 2 ½ Diesel 0 2 ½ Petrol 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on 8 110 8 110	1983/ 1983/ 1983/ 1983/ 1984/ 1984/ 1984/ 1986/ 1986/ 1992/	Bottom Top Bottom Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC3664 NRC6404 NRC3976 NRC4850 NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1454 110 1455 110 1456 110 1457 111 1598 90 1599 90 1600 90 441 90 1661 110 1673 110 1838 110 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960 2024 De	0 4 cylinder Petrol 0 2 ¼ Diesel & 2 ½ Diesel 0 2 ¼ Diesel & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel & 110 2 ½ Diesel 0 2 ½ Petrol 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1983/ 1983/ 1983/ 1983/ 1984/ 1984/ 1984/ 1986/ 1986/ 1992/	Bottom Top Bottom Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC6404 NRC3976 NRC4850 NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1455 110 1456 110 1457 110 1598 90 1599 90 1600 90 441 90 1661 110 1673 110 1838 110 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960 2024 De	0 2 ½ Diesel & 2 ½ Diesel 0 2 ¼ Diesel & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel 8 110 0 2 ½ Petrol 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on 8 110 8 110	1983/ 1983/ 1983/ 1984/ 1984/ 1984/ 1986/ 1986/ 1992/	Bottom Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC3976 NRC4850 NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1456 110 1457 110 1598 90 1599 90 1600 90 441 90 1661 110 1676 110 1838 111 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960 2024 De	0 2 ¼ Diesel & 2 ½ Diesel 0 4 cylinder Petrol & 2 ½ Diesel & 110 0 2 ½ Diesel & 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1983/ 1983/ 1984/ 1984/ 1984/ 1986/ 1986/ 1992/	Bottom Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC4850 NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1457 110 1598 90 1599 90 1600 90 441 90 1661 110 1676 1110 1873 1111 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960	0 4 cylinder Petrol & 2 ½ Diesel & 110 2 ½ Diesel & 110 2 ½ Diesel & 110 2 ½ Diesel & 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1983/ 1984/ 1984/ 1984/ 1986/ 1986/ 1992/	Expansion tank to pump Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC4850 NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1598 90 1599 90 1600 90 441 90 1661 110 1676 1110 1838 111 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960	& 110 2 ½ Diesel & 110 2 ½ Diesel & 110 2 ½ Diesel & 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1984/ 1984/ 1986/ 1986/ 1986/ 1992/	Bottom radiator Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC4844 NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1599 90 1600 90 441 90 1661 111 1676 110 1838 111 1836 90 1837 90 1899N 1910N 1936 111 1852 1853 1561 1960 2024 De	& 110 2 ½ Diesel & 110 2 ½ Diesel & 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1984/ 1984/ 1986/ 1986/ 1986/	Bottom engine to connection Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC4842 NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1600 90 441 90 1661 111 1676 111 1838 111 1836 90 1837 90 1899N 1910N 1936 111 1852 1853 1561 1960	& 110 2 ½ Diesel & 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1984/ 1986/ 1986/ 1986/	Expansion tank By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC4837 ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
441 90 1661 110 1676 1110 1673 1110 1838 1111 1836 90 1837 90 1899N 1910N 1936 1110 1852 1853 1561 1960	& 110 0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1986/ 1986/ 1986/	By-pass By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	ERC5654 NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1661 110 1676 110 1673 110 1838 110 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960	0 2 ½ Petrol 0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1986/ 1986/ 1992/	By-pass Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC5503 NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1676 110 1673 110 1838 110 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960	0 2 ½ Diesel 0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1986/ 1986/ 1992/	Top Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NTC2029 NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1673 111 1838 111 1836 90 1837 90 1899N 1910N 1936 111 1852 1853 1561 1960	0 2 ½ Diesel 0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1986/ 1992/	Bottom with heater Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NTC3453, NTC1707 NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1838 110 1836 90 1837 90 1899N 1910N 1936 110 1852 1853 1561 1960	0 2 ½ Petrol & Diesel VIN-FA389799 on & 110 & 110	1992/	Top Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NTC3069 NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1836 90 1837 90 1899N 1910N 1936 111 1852 1853 1561 1960	& 110 & 110		Heater feed & return RH side Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC6308 NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1837 90 1899N 1910N 1936 111 1852 1853 1561 1960	& 110 Man Rover 3 SER up to VIN EA339625 0		Heater feed & return LH side Breather Thermostat adaptor Heater Heater	NRC6309 543766 543767, ESR1287 ERC7510 ETC6889 ETC6890
1910N 1936 111 1852 1853 1561 1960 2024 De	0		Thermostat adaptor Heater Heater	543767, ESR1287 ERC7510 ETC6889 ETC6890
1910N 1936 111 1852 1853 1561 1960 2024 De	0		Thermostat adaptor Heater Heater	543767, ESR1287 ERC7510 ETC6889 ETC6890
1936 111 1852 1853 1561 1960 2024 De			Thermostat adaptor Heater Heater	ERC7510 ETC6889 ETC6890
1852 1853 1561 1960 2024 De			Heater Heater	ETC6889 ETC6890
1853 1561 1960 2024 De	efender		Heater	ETC6890
1561 1960 2024 De	efender			
2024 De	efender		Ton	
	efender		ТОР	NRC9710
1894			Heater	BTR215
1034			Bottom	NTC3543
521 Ra	inge Rover without air conditioning	1970/	Тор	575718, GRH551
	inge Rover with air conditioning	1970/	Тор	634301
	inge Rover	1970/	Bottom	575719, 598871, GRH550
	inge Rover	1970/	Rear heater	NRC2523
	inge Rover	1970/	Rear heater	NRC2524
1188 Ra	inge Rover to engine suffix C	1970/	Pump to inlet manifold	610689
	inge Rover to engine suffix C	1970/	Front heater	610688
	inge Rover from engine suffix C	a the stail	Front heater	ERC2319, ERC2278
	inge Rover from engine suffix C		Front heater	ERC2320
	ensity of the second	0.01	18 <u>0</u> 0UN 85 DISDA	
	inge Rover	1986/	Top	NTC1081
	inge Rover		Тор	ESR1052
	inge Rover, V8		Breather	611109
	nge Rover, V8		Flame trap	611114
	nge Rover, V8		Breather filter/cylinder block	
	nge Rover, V8		Breather	90611112
1956N Ra	nge Rover, V8		Rocker cover to carburettor	611113
1883 Ra	nge Rover (Australia only)	/86	Тор	NRC2258
1931 Dis	scovery 200 Tdi	1989/94	Тор	NTC4320
	scovery 200 Tdi	1989/94	Bottom	NTC4329
		1989/94		NTC7223
	scovery 200 Tdi, engine 0754A on scovery 200 Tdi		By-pass	ERR1361
	scovery 200 Tdi	1989/94	Thermostat to pipe	ERR372
	scovery 200 Tdi	1989/94 1989/94	Heater inlet Heater outlet	MXC4931 MXC4932
1965 Dis	scovery V8 up to engine no. KA064754	1989/	Bottom	NTC5632
1979			Inlet	NTC2842
1980			illot	NTC2843
1981				
1982			Top	NTC2841
			Тор	ESR2298
1983			Pottom	NTC4895
1984			Bottom	ESR536
1985	ngo Pover 2 FEE up to VIN FASSCOS		Bottom	ESR3121
	nge Rover 3.5Efi up to VIN EA336625		Bottom	NTC1174
2001			By-pass	ERR1424
2002	on to while all was to		Top	ESR2866, PCH114840
2003			Bottom	ESR2914, PEH101010
2026P	MR HALL THE MALCH		Fuel	543765, ESR1287

The minimum order off any tool is 10 off.